

Oil-Only DrumTop Pads #BTOP - 22", 25 pads/package



Eliminate messy drum tops with these Sorbent Oil-Only DrumTop Pads.

- Absorb drips from leaking pumps and help keep drum storage areas looking good
- Pre-cut bung holes make for easy access to drum
- Pads can be removed and replaced with pumps and valves installed
- Made from top-quality FineFiber Mat
- Color-coding helps you visually identify the right sorbent for your needs. Blue designates Oil-Only sorbency for oil and other petroleum-based fluids — but not water; fits into many professional surroundings.

BTOP Specifications

| | |
|-----------------------------|----------------------------|
| Dimensions: | ext. dia. 22" |
| Shipping Dimensions: | 23" W x 23" L x 4" H |
| Sold as: | 25 pads per package |
| Color: | Blue |
| Composition: | Polypropylene |
| Absorbency: | Up to 8.6 gal. per package |
| Absorbency per: | Up to 44 oz. per pad |
| Weight: | 7 lbs. |
| # per Pallet: | 72 |
| Basis Weight: | HeavyWeight |
| Incinerable: | Yes |
| Ship Class: | 175 |

Metric Equivalent Specifications

| | |
|-----------------------------|--------------------------------|
| Dimensions: | ext. dia. 55.9cm |
| Shipping Dimensions: | 58.4cm W x 58.4cm L x 10.2cm H |
| Dimensions: | |
| Absorbency: | Up to 32.6 L per package |
| Absorbency per: | Up to 1.3 L per pad |
| Weight: | 3.2 kg |

BTOP Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

29 CFR 1910.107(g)(2) - OSHA requires spraying areas to be "kept as free from the accumulation of deposits of combustible residues as practical."

29 CFR 1910.107(b)(3) - If floors in a spray booth or work area are combustible, they "shall be covered with noncombustible material of such character as to facilitate the safe cleaning and removal of residues."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Safety Data Sheet (SDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
sales@spilltech.com